



**Wildcat**  
by Griffiths Equipment

## WILDCAT BOSS KITS

<u>PART NO</u>	<u>PART NO</u>		<u>YEAR OF</u>
<u>13D WHEEL</u>	<u>ALL OTHERS</u>	<u>MODEL</u>	<u>MANUFACTURE</u>

### AUSTIN

B104	B104	1100 & 1300 MK 1	62-67
B102	B102	1100 & 1300 MK2	67-75
B102	B102	Allegro	75-80
B106	B106	Healey MK 1 & 2	
B107	B107	Healey MK 3 & 4	
B102	B102	Maxi	69-78
B100	B100	Mini MK 1	60-67
B101	B101	Mini MK 2, Clubman	67-81
B102	B102	Princess	77-82

### CHRYSLER

B120	B120	Valiant AP5,AP6,VC-VG	63-71
------	------	-----------------------	-------

### DATSUN-SEE NISSAN

### FORD

B350	C350	105E	61-66
B350	C350	Capri MK1	69-74
B356	C356	Capri MK 1 & 2	74-78
B350	C350	Cortina MK 1 & 2	63-71
B355	C355	Cortina MK 3, TC-TD	71-77
B352	B352	Cortina MK 4,5,TE,TF	77-83
B353	C353	Escort MK 1 to 68	67-68
B350	C350	Escort MK 1 68 on	68-76
B354	C354	Escort MK 2	76-82
B358	C358	Falcon XR,XT,XW,XY,XA	66-74
B359	C359	Falcon XB,XC,XD,XE	74-85
B360	B360	Falcon EA, EB,ED	88-96
B361	B361	Falcon XF (Auto Only)	85-87



**Wildcat**  
by Griffiths Equipment

## **WILDCAT BOSS KITS**

<b><u>PART NO</u></b>	<b><u>PART NO</u></b>	<b><u>MODEL</u></b>	<b><u>YEAR OF MANUFACTURE</u></b>
<b><u>13D WHEEL</u></b>	<b><u>ALL OTHERS</u></b>		
B366	B366	Laser Sedan, Hatchback	81-96
B366	B366	Telstar Sedan, TX5	83-96
B367	B367	Telstar Sedan TX5 with Short Shroud	92-96
B357	C357	Zephyr MK 2 & 3	53-68
<b><u>HILLMAN</u></b>			
B882	B882	Avenger	70-80
B880	B880	Minx, Humber 80, 90	51-67
B350	C350	Hunter, Imp, Vogue 67 on	60-78
<b><u>HOLDEN</u></b>			
B440	C440	Holden FE,FC,FB,EK,EJ,EH,HD,HR	56-66
B441	C441	Holden HK,HT,HG	68-71
B442	B442	Holden HQ,HJ,HX,HZ,WB	71-86
B884	B884	Barina	85 on
B115	B115	Bedford CF Van	69-84
B443	C443	Camira	82-89
B442	B442	Commodore VB,VC,VH,VK	78-86
B444	B444	Commodore VN,VP (not 13D wheel)	89-93
B443	C443	Gemini Aust and Jap assembled	75-89
B442	B442	Sunbird	77-83
B441	C441	Torana LC	71-73
B442	B442	Torana LJ,LH,LX,UC	73-83
<b><u>HONDA</u></b>			
B500	B500	Accord	77 on
B500	B500	City	84-86
B500	B500	Civic	73 on
B500	B500	Prelude (without Cruise Control)	79-90
B500	B500	Integra	-93
B500	B500	CRX	-89





**Wildcat**  
by Griffiths Equipment

## **WILDCAT BOSS KITS**

<u>PART NO</u>	<u>PART NO</u>	<u>MODEL</u>	<u>YEAR OF MANUFACTURE</u>
<u>13D WHEEL</u>	<u>ALL OTHERS</u>		
B113	C113	Minor 1000	51-62
B100	B100	Mini MK 1	60-67
B101	B101	Mini MK 2, Clubman	67-81
B104	B104	1100 & 1300 MK 1	62-67
B102	B102	1100 & 1300 MK 2	67-75
<b><u>NISSAN-DATSUN</u></b>			
B130	C130	1200, 120Y	70-78
B131	C131	1600,140J,160J Violet, 240Z,260Z	69-78
B132	C132	100A Cherry	76-80
B134	B134	180B, 200B	72-80
B135	B135	200 SX RS13	89-93
B134	B134	Bluebird	80-83
B135	B135	Bluebird U11,U12	83-90
B135	B135	Pathfinder	88-91
B134	B134	Patrol Safari	-87
B136	B136	Patrol Safari	87-91
B132	B132	Pulsar	81-87
B134	B134	Safari N ARG161	83-87
B136	B136	Safari VRY60	87-91
B134	B134	Skyline HR30	83-85
B136	B136	Skyline HR32	89-91
B134	B134	Sunny RWD	78-83
B135	B135	Sunny FWD	83-87
B136	B136	Sentra	87-95
B135	B135	Terrano	88-91
<b><u>SUZUKI</u></b>			
B885	B885	Alto 2 door	81-85
B884	B884	Alto 4 door	81-85
B885	B885	Hatch	82-85



**Wildcat**  
by Griffiths Equipment

## **WILDCAT BOSS KITS**

<u>PART NO</u>	<u>PART NO</u>	<u>MODEL</u>	<u>YEAR OF MANUFACTURE</u>
<u>13D WHEEL</u>	<u>ALL OTHERS</u>		
B884	B884	Swift	85 on
B885	B885	Van ST80, ST90	78-85
B884	B884	4x4 LF10, 2, 50, 80, 81	74-81
B886	B886	4x4 SJ410, 413	82 on
<b><u>SUBARU</u></b>			
B845	C845	Legacy & Impreza	All Models
<b><u>TOYOTA</u></b>			
B903	B903	Camry	87 on
B900	B900	Celica LT1600, TA20,22	70-75
B903	B903	Celica TA28, RA23, 28, 40, 60	75-85
B903	B903	Corolla KE30,35,70,71, AE80,82 EE80	75-87
B904	B904	Corolla	88 on
B900	B900	Corona RT40, 80, 84	67-74
B903	B903	Corona RT100 TO 130, TT132 TO 150	74-88
B904	B904	Corona ST171	89 on
B903	B903	Cressida	79-84
B903	B903	Hi-Ace, Hi-Lux, Lite-Ace	71 on
B903	B903	Landcruiser FJ40, FJ55 All Models	-85
B903	B903	Starlet to July 83	79-83
B902	C902	Starlet July 83 on	83 on
<b><u>TRIUMPH</u></b>			
B202	B202	2000, 2500 MK 2	70-79
B106	B106	Herald, Spitfire, Vitesse	65-80
<b><u>VAUXHALL</u></b>			
B211	B211	Chevette	77-81
B210	C210	Viva HA, HB	64-71
B212	C212	Viva HC, Magnum	71-77



**Wildcat**  
*by Griffiths Equipment*

**WILDCAT BOSS KITS**

<u>PART NO</u>	<u>PART NO</u>		<u>YEAR OF</u>
<u>13D WHEEL</u>	<u>ALL OTHERS</u>	<u>MODEL</u>	<u>MANUFACTURE</u>

**VOLKSWAGEN**

B920	C920	Beetle 1200,1300,1500	-74
B921	C921	Beetle 1200,1300,1500	74-79

**MARINE**

B3/4S	C3/4L	Keyway 3/4" taper	
-------	-------	-------------------	--